

Instruktioner

① Mic vol:

+: Mikrofonvolumen skrues op.

-: Mikrofonvolumen skrues ned.

② Remix vol:

+: Ekkoeffekten skrues op.

-: Ekkoeffekten skrues ned.

③ M/POWER:

Kort tryk: Skift mellem tilstande.

Tryk og hold: Tænd/sluk.

④ ►/V+

Kort tryk: Næste sang.

Tryk og hold: Lydstyrken af musikken øges.

⑤ ► II

Kort pres: Afspil og sæt musik på pause.

Kort pres (FM-tilstand): Automatisk frekvenssøgning.

⑥ ◀◀/V-

Kort tryk: Forrige sang.

Tryk og hold: Lydstyrken af musikken mindskes.

⑦ ⚡/LED

Kort tryk: Sluk for vokalen i musikken.

Tryk og hold: Tænd/sluk for LED-lys.

⑧ REC

Optag dig selv synge.

⑨ USB

USB-indgang.

⑩ DC 5 V

DC 5 V: Micro USB-slot til opladning, optagelse, lydindgang og FM-antenne.

⑪ ↻

Lydudgang til hovedtelefoner.

⑫ TF

Micro SD/TF-kort indgang (maks. 32 gb Micro SD HC).

Trådløs musik

1: Tryk på ③ og hold den nede for at tænde for mikrofonen.

2: Naviger til de trådløse indstillinger på din telefon, og find karaokemikrofonen (WS-1816) på listen over tilgængelige enheder, og tilslut.

3: Juster lyd- og ekko-indstillingerne til et passende niveau.

4: Begynd at synge.

Optagelse med smartphone/tablet

1: Tilslut optageledningen. Sæt Micro USB-stikket i Micro USB-porten i mikrofonen og 3,5 mm jack-stikket i din telefon/tablet (kræver muligvis omformer (medfølger ikke)).

2: Åbn optagelsessoftwaren på din telefon/tablet, og tryk på optageknappen på mikrofonen eller i optagelsessoftwaren på din telefon/tablet.

OBS! Musikafspilning er ikke tilgængelig, når du optager med standard software på iOS.

Afspilning fra USB-stik eller Micro SD/TF-kort.

1: Indsæt et USB-stik (ikke inkluderet) i ⑨ eller et Micro SD/TF-kort (ikke inkluderet) i ⑫.

2: Mikrofon skifter automatisk tilstand til afspilning af musik.

3: Musikken starter automatisk.

Opladning

1: Indsæt Micro USB-stikker af opladningskablet i ⑩ og USB-A-stikket i en vægoplader eller en USB-port på en computer, for at oplade mikrofonen.

2: Når mikrofonen oplader, tændes et rødt lys på håndtaget.

3: Når mikrofonen er fuldt opladet, slukkes lyset.

FM-tilstand

1: Når mikrofonen er tændt, tryk på ③ for at skifte til FM-tilstand.

2: Indsæt Micro USB til 3,5 mm jack-stikket i ⑩, det vil fungere som antenne.

3: Tryk en gang på ⑤ for at starte en automatisk søgning efter FM-stationer. Når søgningen er fuldendt, vil mikrofonen hoppe til den først tilgængelige station. Tilgængelige FM-stationer bliver automatisk gemt på mikrofonen.

4: Skift imellem de tilgængelige stationer ved at trykke på ④ og ⑥.

5: Tryk en gang på ⑤ for at starte en ny søgning efter FM-stationer. Dette vil slette eventuelt tidligere gemte stationer.

Specifikationer

Strøm: DC USB 5 V 2.0 A (max)

Batteri: 1800 mAh

Højttalerudgang: 3 W

Følsomhed: 115 dB

FM-radio: 87,5-108 Hz

Spilletid: Op til 8 timer

Opladningstid: Op til 5 timer

Standbytid: Op til 12 timer

Bluetooth version: v 5.0

Bluetooth-navn: WS-1816



Instructions

① Mic vol:

+ : The microphone volume increases.

- : The microphone volume decreases.

② Remix vol:

+ : The microphone echo effect increases.

- : The microphone echo effect decreases.

③ M/POWER:

Short press: Switch between modes.

Long press: Power ON/OFF.

④ ⏮/V+

Short press: Next song.

Long press: Music volume increase.

⑤ ▶ II

Short press: Play and pause music.

Short press (FM mode): Automatic frequency search.

⑥ ⏮/V-

Short press: Previous song.

Long press: Music volume decrease.

⑦ ⚙/LED

Short press: Remove voice track in the music.

Long press: Turn LED lights on/off.

⑧ REC

Record yourself singing.

⑨ USB

USB slot.

⑩ DC 5 V

DC 5 V: Micro USB slot for charging, recording, audio line in, and FM antenna.

⑪ 🔊

Audio output for headphones.

⑫ TF

Micro SD/TF card slot (max. 32 gb Micro SD HC).

Wireless music

1: Press and hold the ③ to turn on the microphone.

2: Navigate to the wireless settings on your phone and find the karaoke microphone (WS-1816) on the list of accessible devices, and connect.

3: Adjust the sound and echo settings to a suitable level.

4: Start singing.

Recording with smartphone/tablet

1: Connect the recording wire. Insert the Micro USB plug into the Micro USB port in the microphone and the 3.5 mm jack into your phone/tablet (may require a converter (not supplied)).

2: Open a recording software on your phone/tablet and press record button on microphone or in the recording software on you phone/tablet.

OBS! Music playback is not available when recording with standard software on iOS.

USB stick or Micro SD/TF card playback.

1: Insert USB stick (not included) into ⑨ or a Micro SD/TF card (not included) into ⑫.

2: Microphone will automatically switch mode to play music.

3: Music will play automatically.

Charging

1: Insert the Micro USB end of the charging cable into ⑩ and the USB-A end into a wall charger or a USB port in a computer to charge.

2: When charging, a red light on the handle will turn on.

3: When fully charged, the light will turn of.

FM mode

1: When the microphone is on power, press ③ to switch to FM mode.

2: Plug the Micro USB into the 3.5mm jack into ⑩, it will act as an antenna.

3: Press ⑤ once to start an automatic search for FM stations. When the search is completed, the microphone will jump to the first found station. FM stations are automatically stored on the microphone.

4: Switch between the found stations by pressing ④ and ⑥.

5: Press ⑤ once to start a new search for FM stations. This will delete previously saved stations.

Specifications

Power: DC USB 5 V 2.0 A (max)

Battery: 1800 mAh

Speaker output: 3 W

Sensitivity: 115 dB

FM Radio: 87.5-108 Hz

Playtime: Up to 8 hours

Charging time: Up to 5 hours

Standby time: Up to 12 hours

Bluetooth version: v 5.0

Bluetooth name: WS-1816

