

TRÅDLØS HØJTALER BRUGERMANUAL

1. ÆSKENS INDHOLD

Pak din Bluetooth-højtaler ud af emballagen, og kontroller, at du har alle komponenterne:

- 1x trådløs højtaler
- 1x Micro USB-opladningskabel

2. OPLAD DIN HØJTALER

Før første brug anbefales det, at du oplader din Bluetooth-højtaler i mindst 1 time. Tilslut det medfølgende Micro USB-ladekabel til Micro USB-porten i bunden af Bluetooth-højtaleren (dette er dækket af en gummipakning). Tilslut den anden ende til en USB-port på din computer eller USB-vægoplader (ikke inkluderet).

3. TÆND/SLUK

Tænd/sluk-knappen "⏻".

4. TILSLUTNING TIL HØJTALER

Mens Bluetooth-højtaleren er slukket, skal du trykke på og holde tænd/sluk-knappen nede i 3-4 sekunder, Bluetooth-højtaleren tændes og går automatisk i paringstilstand efterfulgt af en lyd. Aktivér Bluetooth-funktionen på din smartphone eller tablet. Søg efter enheden "Panda/Unicorn", og tilslut. Når højtaleren er parret med din enhed, giver højtaleren en lyd. Din smartphone husker højtaleren til fremtidig brug.

5. START AUDIO-AFSPILNING

Start afspilning på din smartphone eller tablet. Styr musikken ved hjælp af kontrolpanelet på Bluetooth-højtaleren.

For at øge/sænke lydstyrken skal du trykke på "▶▶" eller "◀◀" knapperne.

For at ændre sang kort skal du trykke på knapperne "▶▶" eller "◀◀".

For at pause/afspille musik kort skal du trykke på "⏸".

6. BRUG AF HÅNDFRIFUNKTION

Tryk kort på "☞", mens telefonen ringer for at besvare et indgående opkald;

Tryk kort på "☞" for at afslutte opkaldet.

Tryk og hold "☞", mens telefonen ringer for at afvise et indgående opkald;

Tryk kort på "☞" to gange for at ringe op til dit sidste kaldte nummer.

Højtaler:	3 W
Rækkevidde:	10 m
Standby-tid:	Op til 40 timer
Spilletid:	Op til 3 timer
Ladetid:	Op til 2,5 timer
Bluetooth-navn:	Panda/Unicorn

I tilfælde af problemer eller spørgsmål til produktet, kontakt da venligst importøren på: info@nohro.dk eller +45 6913 2121.

WIRELESS SPEAKER USER MANUAL

1. BOX CONTENT

Unpack your Bluetooth Speaker from the packaging and check you have all the components:

- 1x Wireless Speaker
- 1x Micro USB Charging Cable

2. CHARGE YOUR SPEAKER

Before first use, it is recommended that you charge your Bluetooth speaker for a minimum of 1 hour. Connect the supplied Micro USB charging cable to the Micro USB port on the bottom of the Bluetooth speaker (this is covered by a rubber seal). Connect the other end to a spare USB port on your computer or USB wall charger (not included).

3. POWER ON/OFF



Turn on/off button “”.

4. CONNECTING TO SPEAKER

While the Bluetooth speaker is off, press and hold the power button down for 3-4 seconds, the Bluetooth speaker will turn on and enter pairing mode automatically followed by a sound. Activate the Bluetooth feature on your smartphone or tablet. Search for the device “Panda/Unicorn” and connect. When the speaker is successfully paired with your device the speaker will make a sound. Your smartphone will remember pairing with the speaker for future use.

5. START AUDIO PLAYBACK


Start audio playback on your smartphone or tablet. Control the volume and track playback using the controls located on the Bluetooth speaker.

To increase/decrease the volume, press and hold the “” or “” buttons.


To change songs short press the “” or “” buttons.

To pause/play music short press the “”.

6. USING THE HANDSFREE FUNCTION

Short press the “” while the phone is ringing to answer an incoming call;

Short press the “” to end the call;

Long press the “” while the phone is ringing to reject an incoming call;

Short press the “” twice to dial your last number called.

Speaker:	3 W
Range:	10 m
Standby time:	Up to 40 hours
Play time:	Up to 3 hours
Charging time:	Up to 2.5 hours
Bluetooth name:	Panda/Unicorn

In case of problems or questions about the product, please contact the importer at: info@nohro.dk or +45 6913 2121.