

TRÅDLØSE HØRETELEFONER WIRELESS EARPHONES



nohro

DK

Et sæt trådløse TWS høretelefoner. Højre og venstre høretelefoner har fuld Bluetooth funktion, så de kan bruges sammen eller hver for sig.

Opret forbindelse:

Sørg for at der er strøm på høretelefonerne. Tag høretelefonerne ud af opladerboksen, for at aktivere dem. De vil blinke skiftevis blå og rød, for at indikere at de er aktive og søger efter enheder. På din enhed, find "TWS4" på listen over tilgængelige enheder, og opret forbindelse. Når der er oprettet forbindelse, vil høretelefonerne stoppe med at blinke og en tone vil lyde i høretelefonerne.

Vær opmærksom på at høretelefonerne kun er aktive, når de er taget ud af opladerboksen. Når de sidder i opladerboksen, går de automatisk i standby-tilstand, og vil tænde automatisk igen, når de tages ud af opladerboksen.

Funktioner:

Når høretelefonerne sidder i opladerboksen kan du trykke på knappen i boksen, for at få vist batteriniveauet.

Dobbeltryk for at genkalde seneste indgående/udgående nummer. Tryk én gang for at modtage opkald, eller start/pause musikken. Tryk på høretelefonerne i 3 sekunder for at slukke dem.

Tryk igen for at tænde høretelefonerne igen.

Opkald:

For at modtage et opkald, når høretelefonerne er forbundet med en smartphone, tryk én gang på enten højre eller venstre høretelefon. Tryk én gang på enten højre eller venstre høretelefon, for at afslutte opkaldet. Når der afspilles musik, kan du dobbeltrykke på enten højre eller venstre høretelefon for at ringe op til det sidste indgående/udgående opkald.

Opladning:

Sæt den medfølgende USB-A til Micro USB-stik i opladerboksen, og i et USB-stik i en computer eller vægoplader. Sørg for at begge høretelefoner sidder korrekt i opladerboksen. De fire dioder på opladerboksens front vil lyse op, for at indikere strømiveauet. Når alle fire dioder lyser op, er opladerboksen fuldt opladet. Under opladningen vil høretelefonerne lyse rødt for at indikere opladning. Når de er fuldt opladt, vil lyset skifte til blå. Høretelefonerne skal sidde i opladerboksen for at kunne lade op. Når du er på farten, kan du bruge opladerboksen som ekstra strøm til dine høretelefoner. Opladerboksen kan give dig 10 timer ekstra batteritid. Sæt høretelefonerne i opladerboksen og den kan fuldt oplade dine høretelefoner op til 2 gange ekstra.

Specifikationer:

Bluetooth version:5.0
Rækkevidde:Op til 10 m
Batteri høretelefoner:55 mAh
Batteri opladerboks:450 mAh
Standbytid:Op til 60 timer
Spilletid:Op til 5 timer
.....Op til 15 timer med opladerboksen
Opladetid:Op til 1 time
Strøm:USB 5 V
Opladerkabel medfølger:26 cm
Følsomhed:97 dB ± 3 dB

Sved- og vandafvisende

Ofte stillede spørgsmål:

Lyden er ustabil: Sørg for at høretelefonerne er inden for rækkevidde af den enhed de er forbundet til. Fjern forbindelsen til høretelefonerne, og opret på ny forbindelse. Sørg for at der er strøm på høretelefonerne. Stå ikke ved siden af WiFi og lignende, da det kan have indvirkning på signalet.

Jeg kan ikke finde høretelefonerne på listen over tilgængelige produkter: Sørg for, at der er strøm på høretelefonerne. Sæt dem eventuelt i opladerboksen.

OBS! Lad ikke produktet blive vådt. Udsæt ikke produktet for ekstrem varme eller åben ild.

A set of TWS wireless earphones. The left and right earphones have full Bluetooth functionality, so you can use them together or separately.

Connect:

Make sure the earphones are powered on. To activate, remove the headphones from the charger box. They will flash alternately blue and red to indicate that they are active and searching for devices. On your device, find "TWS4" in the list of available devices and connect. Once connected, the earphones will stop flashing and a tone will sound in the headphones.

Please note that the earphones are only active when removed from the charger box. When they are in the charger box, they automatically go into standby mode and will turn on automatically when removed from the charger box.

Features:

When the earphones are in the charger box, you can press the button in the box to view the battery level. Double tap to recall the latest incoming/outgoing number. Press once to receive calls or start/pause the music.

Press the earphones for 3 seconds to turn them off. Press again to turn on the earphones again.

Call:

To receive a call when the earphones are connected to a smartphone, press either the right or left earphone once. Press either right or left earphone once to end the call. When playing music, you can double-tap either the right or left earphone to dial the last incoming / outgoing call.

Charging:

Insert the supplied USB-A to Micro USB connector into the charger box and into a USB connector on a computer or wall charger. Make sure both earphones are placed correctly in the charger box. The four LEDs on the front of the charger box will light up to indicate the power level. When all four LEDs light up, the charger box is fully charged. During charging, the headphones will light red to indicate charging. When fully charged, the light will change to blue. The headphones must be in the charger box to charge. On the go, you can use the charger box as extra power for your headphones. The charger box can give you 10 hours of extra battery life. Plug the headphones into the charger box and it can fully charge your headphones up to 2 times extra.

Specifications:

Bluetooth version:5.0
 Range:Up to 10 m
 Battery headphones:50 mAh
 Battery charger box:450 mAh
 Standby time:Up to 60 hours
 Playtime:Up to 5 hours
Up to 15 hours with the charger box
 Charging time:Up to 1 hour
 Power:.....USB 5 V
 Charging cable included:26 cm
 Sensitivity:97 dB ± 3 dB
 Sweat and water repellent

Frequently asked questions:

Sound is unstable: Make sure the headphones are within range of the device they are connected to. Disconnect the headphones and reconnect. Make sure the headphones are powered. Do not stand next to WiFi and the like, as it may affect the signal.

I can't find the headphones in the list of available products: Make sure the headphones are powered. Optionally, put them in the charger box.

NOTE! Do not let the product get wet. Do not expose the product to extreme heat or open flames.

I tilfælde af problemer eller spørgsmål til produktet, kontakt da venligst importøren på:
 info@nohro.dk eller +45 6913 2121.

In case of problems or questions about the product, please contact the importer at: info@nohro.dk or +45 6913 2121.