TRÅDLØSE HOVEDTELEFONER

WIRELESS HEADPHONES

DK



PRODUKTOVERSIGT

① Skru op for volumen/næste sang
② Skru ned for volumen/ forrige sang
③ Mikro USB-indgang til opladning
④ Lysindikator
⑤ 3,5 mm lydindgang
⑥ Mikro SD/TF kort indgang
⑦ Tænd/sluk, play/pause, modtage/afslutte opkald
⑧ Mikrofon

For korrekt og sikkert brug af hovedtelefonerne, bedes du læse denne brugermanual nøje.

PRODUKTEGENSKABER

1. Bluetooth version: Version 5.0
2. Understøtter Bluetooth samtaler og musik.
3. Indbygget litium-ion batteri. Oplades gennem Mikro USB-indgangen.
4. Strømsparefunktion (Hovedtelefonerne slukker automatisk efter 5 minutter, hvis de ikke har skabt forbindelse til en Bluetooth enhed).

PRODUKTSPECIFIKATIONER

1. Transmissionsområde: Op til 10 m
2. Frekvensområde: 20 Hz - 20 kHz
3. Følsomhed: 113 dB ± 3 dB
4. Impedans: 32 Ω
5. Højtalerstørrelse: 40 mm
6. Opladningstid: Op til 1,5 time
7. Taletid: Op til 12 timer
8. Spilletid: Op til 12 timer
9. Standby-tid: Op til 80 timer
10. Batterikapacitet: 300 mAh
11. Bluetooth navn: BT HP

INSTRUKTIONER

Bluetooth funktion:

1. Opret forbindelse:

Tryk og hold "switch" i 2 sekunder for at tænde hovedtelefonerne. Lyset i hovedtelefonerne blinker skiftevis rød og blå. På en enhed med Bluetooth funktion, naviger da til listen over tilgængelige enheder og vælg "BT HP".

Når der er oprettet forbindelse imellem din enhed og hovedtelefonerne, så blinker lyset blåt hvert 5. sekund. Hvis hovedtelefonerne slukkes, så vil de, næste gang de bliver tændt, automatisk forbindes til den enhed de sidst var tilsluttet til. Naviger til listen på din enhed, for at afbryde forbindelsen igen, eller sluk hovedtelefonerne (tryk og hold "switch" inde i 5 sekunder).

2. For at afspille musik og modtage opkald:

2.1. Tryk "switch" én gang for at afspille musik. Tryk igen for at pause musik.

2.2. For at modtage og afslutte opkald: Når du modtager et opkald, tryk "switch" for at tage telefonen, tryk "switch" igen for at afslutte.

2.3. For at afvise et opkalde: Tryk og hold "switch" i 2 sekunder for at afvise et opkald.

2.4. For at ringe op igen, til det sidste nummer du har ringet til: Dobbeltklik på "switch".

2.5. Tryk og hold " ▸ " (A) inde for at skifte til næste sang. Tryk én gang for at skrue op for lyden. Når hovedtelefonerne når maksimal volumen, indikerer de med en lyd.

2.6. Tryk og hold " ◂ " (B) inde for at skifte til forrige sang. Tryk én gang for at skrue ned for lyden.

2.7. Når hovedtelefonerne er forbundet til en enhed med Bluetooth funktion, tryk og hold "switch" i 1 sekund (C) for at aktivere Siri. Tryk og hold i 3 sekunder for at afslutte Siri (virker kun på iOS).



2.8. (D) For at bruge det medfølgende audio-kabel, indsæt den ene ende af kablet i hovedtelefonerne, og den anden ende af kablet i et 3,5 mm jackstik i din enhed eller en computer. Hovedtelefonerne vil automatisk slukke, når jackstikket isættes.



3. For at oplade hovedtelefonerne:

3.1. Indsæt Micro USB-stikket i hovedtelefonerne og USB-stikket i en computer eller vægoplader (ikke inkluderet). Et rødt lys tændes når hovedtelefonerne oplades. Lyset slukkes, når hovedtelefonerne er fuldt opladet. Tænd ikke for hovedtelefonerne under opladning.

3.2. Hovedtelefonerne giver en lyd, når strømniveauet bliver lavt.

4. Hovedbåndet

4.1. Hovedbåndet kan justeres, så det passer til dit hoved, ved at forlænge højtalerarmene i hver side.

4.2. Hvis hovedtelefonerne forkommer stramme, kan du med fordel forsigtigt bukke hovedbåndet bagover, så det bliver udvidet en smule. Vær dog forsigtig, så hovedbåndet ikke knækker.

I tilfælde af problemer eller spørgsmål til produktet, kontakt da venligst importøren på: info@nohro.dk eller +45 6913 2121.

Alle registrerede varemærker tilhører deres respektfulde ejere og har intet at gøre med dette produkt.

Nohro ApS
info@nohro.dk

WIRELESS HEADPHONES

EN



PRODUCT DIAGRAM

① Volume up/next song
② Volume down/previous song
③ Micro USB charging port
④ Indicator light
⑤ 3.5 mm audio port
⑥ Micro SD/TF card slot
⑦ Power on/off, play/pause, pick/hang up a call
⑧ Microphone

In order to use the headphones correctly and safely, please read this user manual carefully.

PRODUCT FEATURES

1. Bluetooth Version: Version 5.0
2. Supports Bluetooth calls and music.
3. Built-in lithium-ion battery. Can be charged using Micro USB port.
4. Smart power-saving function (Auto power-off, if it does not pair with a Bluetooth device after 5 minutes).

PRODUCT SPECIFICATIONS

1. Transmission range: Up to 10 m
2. Frequency range: 20 Hz – 20 kHz
3. Sensitivity: 113 dB ± 3 dB
4. Impedance: 32 Ω
5. Speaker size: 40 mm
6. Charging time: Up to 1.5 hours
7. Talk time: Up to 12 hours
8. Playing time: Up to 12 hours
9. Standby time: Up to 80 hours
10. Battery capacity: 300 mAh
11. Bluetooth name: BT HP

OPERATION INSTRUCTIONS

Bluetooth function:

1. Bluetooth pairing:

Press and hold "switch" for 2 seconds to turn on the headphones. When it enters into pairing mode, a red and blue light flashes alternately. On a Bluetooth enabled device, navigate to the Bluetooth name "BT HP". After successful Bluetooth connection, the blue light flashes every 5th seconds. If turned off, the headphones will reconnect with the last device it was connected to, when turned on again. On a Bluetooth enabled device, navigate to the list to disconnect from the headphones, or press and hold "switch" for 5 seconds to turn off the headphones.

2. To play music or make phone call:

2.1. Press "switch" once to play music and press again to pause.

2.2. To answer or hang up a call: When there is an incoming call, press "switch" once to pick up, and press again to hang up.

2.3. To reject a call: Long press "switch" for 2 seconds to reject an incoming call.

2.4. To redial the last number you have dialled: Double tap "switch".

2.5. Long press " ▸ " (A) to go to the next song, and short press to increase volume. When it reaches the highest volume, it will make a sound.

2.6. Long press " ◂ " (B) to go to the previous song and short press to decrease volume.

2.7. When the headphones are successfully connected with a Bluetooth enabled device, press and hold "switch" for 1 second (C) to wake up Siri; long press for 3 seconds to turn it off (Works only with iOS).



2.8. (D) When you need an AUX input, you can plug one end of the included audio cable (3.5 mm jack) into your device or computer, and another end into the 3.5 mm audio port on the headphones. If the headphones are turned on, then they will automatically turn itself off when the audio cable is pluged in.



3. To charge the earphones:

3.1. Plug one end of the included charging cable into a computer or wall charger (not included) and another end of the charging cable into the Micro USB port on the headphones. A red light is on during charging and turns off, when the headphones are fully charged. Do not turn on the headphones when charging.

3.2. The headphones will give a sound, when the power is low.

4. The headband

4.1. The headband can be adjusted to fit your head by extending the speaker arms on each side.

4.2. If the headphones are to tight, you may want to gently bend the headband backwards to expand it slightly. However, be careful not to break the headband.

In case of problems or questions about the product, please contact the importer at: info@nohro.dk or +45 6913 2121.

All registered trademarks belongs to their respectful owners and has nothing to do with this product.

Nohro ApS
info@nohro.dk