

## OPLADNING

På højre side af høretelefonen, tilsluttes Mikro USB kablet i micro USB ladeporten. Tilslut den anden ende af stikket til en USB-enhed (computer, væglader, i bilen osv.)

Et rødt LED-lys indikerer, at høretelefonerne er ved at blive opladet.

Når høretelefonerne er fuldt opladet, vil lyset skifte fra rødt til blå.

Ladetid er ca. 2 timer.

## TÆND/SLUK

Tryk og hold power-knappen inde på højre side af høretelefonerne i omkring 3 sekunder.

Høretelefonerne vil give et bip, og et blå/rødt LED lys vil lyse, for at indikere at høretelefonerne er tændt.

Sluk de trådløse høretelefoner ved at tryk og hold power-knappen inde i 5 sekunder, indtil LED-lyset slukkes.

## FORBIND MED NY ENHED

Tænd de trådløse høretelefoner (se evt. "Tænd/Sluk"-sektionen).

For at parre høretelefonerne med en ny enhed, vil det blå/røde LED-lys blinke for at indikere, at den er klar til at blive parret med en anden enhed.

På din Bluetooth-tilgængelige smartphone, tablet eller media player, skal du gå under Bluetooth indstillingsmenuen, tænd for Bluetooth, og søg efter din nye enhed.

Efter få sekunder vil du se "Nohro Kids BT".

Tryk på "Nohro Kids BT" for at vælge denne. Et fast blå LED-lys vil nu indikere, at din enhed succesfuldt er forbundet med dine nye høretelefoner.

Efter parring af de to enheder, vil høretelefonerne automatisk forbindes når Bluetooth er tændt og inden for rækkevidde.

Høretelefonerne kan kun være parret med én enhed af gangen.

**NOTE: Hvis høretelefonerne ikke har været brugt i 5 minutter, vil de automatisk slukke for at spare på batteriet.**

## SPECIFIKATIONER

Bluetooth version: V 4.2

Rækkevidde: Op til 10 m

Højttaler dimension: Ø40 mm

Lithium batteri: 200 mAh

Tale/musik tid: Op til 4 timer

Opladningstid: Op til 2 timer


Standbytid: Op til 160 timer

Sensitivitet: 85dB ± 3dB ved 1 kHz

Frekvensområde: 20 Hz - 20 kHz

Impedans: 32 Ω

## PRODUKTDIAGRAM



## CHARGING

At the right side of the headphone, connect the micro USB cable to the micro USB charging port.

Connect the other end of the connector to a USB device (computer, wall charger, car, etc.)

A red LED-light indicates that the headphones are being charged.

When the headphones are fully charged, the light will change from red to blue.

Charging time is approx. 2 hours.

## ON/OFF

Press og hold the power-button on the right side of the headphones for about 3 seconds.

The headphones will beep and a blue/red LED will light up, to indicate that the headphones are on.

Turn off the wireless headphones by pressing and holding the power-button for 5 seconds until the LED-light goes out.

## CONNECT WITH NEW DEVICE

Turn on the wireless headphones (see "Switch on/off" section if necessary).

To pair the headphones with a new device, the blue/red LED will flash, to indicate ready to be paired with another device.

On your Bluetooth-enabled smartphone, tablet or media player, go to Bluetooth settings menu, turn on Bluetooth, and search for your new device.

After a few seconds you will see "Nohro Kids BT".

Press "Nohro Kids BT" to select it. A fixed blue LED-light will now indicate that your device is successfully connected to your new headphones.

After pairing the two devices, the headphones will automatically connect, when Bluetooth is lit and within reach.

The headphones can only be paired with one device at a time.

**NOTE: If the headphones have not been used for 5 minutes, they will automatically turn off to conserve battery life.**

## SPECIFICATIONS

Bluetooth version: V 4.2

Range: Up to 10 m

Speaker dimension: Ø40 mm

Lithium battery: 200 mAh

Speech / music time: Up to 4 hours

Charging time: Up to 2 hours

Standby time: Up to 160 hours

Sensitivity: 85dB ± 3dB ved 1 kHz

Frequency range: 20 Hz - 20 kHz

Impedance: 32 Ω

## PRODUCT DIAGRAM

