

QUICK GUIDE

GAMING-HOVEDTELEFONER

GAMING HÖRLURAR
GAMING HEADPHONES

DRIVER SPECIFICATIONS

Diameter: 50mm
Frequency Range: 20Hz-20kHz
Impedance: 20Ω
Sensitivity: 115dB±3dB

MICROPHONE SPECIFICATIONS

Frequency range: 20Hz-16kHz
Mic Impedance: <2.2kΩ
Sensitivity: -42dB±3dB
Directivity: Omnidirectional

GENERAL SPECIFICATIONS

Wire Length: 4m±3cm
Connector Type: USB
Systems: Windows, OSX, Xbox, PS4, Nintendo

PLUG'N'PLAY

No software needed, just connect the USB plug into any free port of your device.

NB! The virtual 7.1 sound works on Windows, with the included software installed



SYSTEM REQUIREMENTS

Windows, OSX, Xbox, PS4, Nintendo

SAFETY

Adjust the volume to a safe level to avoid damaging hearing.

 **USB 2.0**
Universal serial bus



All registered trademarks belongs to their respectful owners and have nothing to do with this product.

QUICK GUIDE

DK

1. Forbind USB-stik for lys og lyd til/fra din enhed.
2. Tænd for din computer/enhed og indstil, hvis nødvendigt, din enhed til at afspille lyden i headsettet.
3. Hvis du har tilsluttet USB-stikket korrekt, vil headsettet nu lyse op i siderne.
4. Ved brug af mikrofonen, skal denne vippes ned foran munden.
5. Indstilling af volumen gøres via kontrollen på headsettet.

NB! Download software fra hjemmesiden, for at benytte 7.1 virtual surround sound på Windows PC.

OBS! Hvis du oplever problemer med din enhed, bedes du kontakte importøren på: info@nohro.dk

SE

1. Anslut USB-kontakt för ljus och ljud till/från enheten.
 2. Slå på datorn/enheten och justera vid behov enheten för att spela upp ljudet i headsetet.
 3. Om du har anslutit USB-kontakten, kommer headsetet nu lysa upp sidorna.
 4. Använd mikrofonen, detta vika ner den främre delen av munnen.
 5. Justera volymen sker via regulatören på headsetet.
- OBS! Ladda ner programvara från webbplatsen, för att använda 7.1 virtuellt surroundljud på Windows PC.


OBS! Om du får problem med enheten, kontakta importören: info@nohro.dk

EN


1. Connect USB connector for light and audio to/from your device.
2. Turn on your computer/device and adjust if necessary your device to play the sound in the headset.
3. If you connected the USB plug correct, the headset will now light up in the sides.
4. Using the microphone, this has to be folded down to the front of the mouth.
5. Adjust the volume via the controller on the headset.

NB! Download software from the website, to use 7.1 virtual surround sound on Windows PC.

ATTENTION! If you experience any problems with your device, please contact the importer: info@nohro.dk



4M CABLE



USB



ADJUSTABLE
HEADBAND

SOFTWARE

Download software på følgende link:
Ladda ner programvara på följande länk:
Download software at the following link:

<http://www.nohro.dk/produkter/gamingheadset/support/>