





LØBECYKEL - BALANCE BIKE





DK

Det er muligt at justere højden på både sadlen og styret så dit barn kan vokse med løbecyklen. Du skal blot løsne møtrikkerne og justere dem til den ønskede højde.

Cyklen kommer usamlet, og skal samles af en voksen. Det anbefales at man løbende efterspænder møtrikker, for at sikre stabiliteten af cyklen. Værktøj er inkluderet.

Brug af cyklen skal ske under opsyn af en voksen og er på eget ansvar. Nohro ApS kan ikke stilles til ansvar for hvordan cyklen er samlet.

Max. belastning: 40 kg

I tilfælde af problemer eller spørgsmål til produktet, kontakt da venligst importøren på: info@nohro.dk eller +45 6913 2121.

EN

It is possible to adjust the height of both the saddle and the handlebar so that your child can grow with the running bike. Simply loosen the nuts and adjust them to the desired height.

The bike comes unassembled and must be assembled by an adult. It is recommended to continuously tighten nuts to ensure the stability of the bike. Tools are included.

Use of the bicycle must be supervised by an adult and is at your own risk. Nohro ApS cannot be held responsible for how the bike is assembled.

Max load: 40 kg

In case of problems or questions about the product, please contact the importer at: info@nohro.dk or +45 6913 2121.