

TR play

Klatresten til trævæg
Climbing rocks for wooden walls

DK: Til montering på trævæg eller træplader med en tykkelse på min. 16 mm og max 22 mm. Kontrollér at klatrestenene er monteret korrekt ved at lade din egen vægt hænge i dem i et par sekunder.

Kundeansvar:

Kunden skal tage alle forholdsregler for at sikre børns sikkerhed.

Advarsel!:

Maksimum brugervægt: 50 kg.

Egnet til børn fra 4 til 10 år.

Maksimum antal brugere er 1.

Montering skal foretages af en voksen.

EN: For mounting on wooden wall or wooden boards with a thickness of min. 16 mm and max 22 mm. Make sure that the climbing stones are mounted securely, by adding your own weight to climbing stones for a few seconds.

Customer responsibilities:

The customer must make all precautions to ensure children's safety.


Warning!:

Maximum user weight is 50 kg.


Suitable for children from 4 to 10 years.

Maximum number of users are 1.

Mounting the climbing rocks should be done by an adult.




1



DK: Bor \varnothing 10 mm huller i den træplade eller trævæg du vil fastgøre klatrestenene på.

EN: Drill \varnothing 10 mm holes in the wooden plate or wooden wall on which you want to attach the climbing stones.


2



DK: Placer 1 A i hvert hul og bank dem i med en hammer til de er plane med væggen.

EN: Place 1 A in each hole and knock them in with a hammer until they are level with the wall.

3



DK: Montér klatrestenene på væggen, ved at bruge 2 skruer pr. klatresten.

EN: Mount the climbing rocks on the wall, using 2 screws for each climbing rock.